

## Read Before Installing


Before installing the LED Tube, disconnect the power to the fixture for safety. Wiring the freezer cooler to use LED Tubes is simple and should be performed by a qualified electrician.

## Ballast and Starter Must Be Bypassed or Removed

You will not need to remove your old tombstone lamp holders to install our LED Freezer/Cooler Tubes.

Once your ballast and or starter are bypassed or removed, mount the LED Tube in your Cooler/Freezer using a small self tapping screw or pop-rivet (not provided). Use the 3 foot waterproof cable to run back to where your ballast was previously installed. Connect your **Line Voltage (L)**, to the **Brown Lead** from the **LED cable**, then connect your **Neutral (N)**, to the **Blue Lead** of the **LED cable**.

1. Remove the old Tube.
2. Remove any ballast and or starter/etc. from the system.
3. Mount LED Tubes in Cooler/Freezer.
4. Run waterproof LED cable back to power.
5. Attach your line voltage to the Brown Wire on LED Tube.
6. Attach your Neutral Voltage to the blue wire on the LED Tube.



## Need Help?

Call Toll Free: (800) 501-5006

[Use Our Fast Help Instant Message](#)

Email: [sales@ledglobalsupply.com](mailto:sales@ledglobalsupply.com)

